



NEW! Now works both with Sagem F@st 3102 modem or Hitachi TECOM H4021 modem

GUIDE TO SERVICES AND OPTIONS on your AngloPack VoIP line

All the services and option on the VoIP line are free of monthly charge (but there might have an usage charge, i.e., call forwarding to a mobile phone is charged as a call to a mobile phone)

Voicemail		
You can check your voicemail by dialling	1 2 3	
Voicemail is activated by default. An incoming call is forwarded to voicemail if you do not answer after 4 rings or directly if your line is already engaged.		
	activation	deactivation
Voicemail direct (without any ringing)	* 7 5 #	# 7 5 #
Call forwarding		
	activation	deactivation
Forwards all calls to another line N°	* 2 1 * + N°	# 2 1 #
Forwards calls to another line N° when no answer	* 2 3 * + N°	# 2 3 #
Privacy		
	activation	deactivation
Avoid displaying your telephone number (only current call)	* 9 2 * + N°	N/A
Avoid displaying your telephone number (always)	* 9 3 #	# 9 3 #
Call waiting		
Call waiting signal is activated by default. When you are in the middle of a call this signal informs you that you have another incoming call.		
Take the second call	2	
Change	R 2	
Hang up one call	R 1	
Deactivate all		
If you need to deactivate all services	* 9 5 #	
Not yet available		
3-way calling / teleconference		

Some other services will be added from time to time. Stay tuned!

Detailed Voicemail Usage

1 2 3

Checking and managing messages	
Hear new messages	automatic
Replay a message	1
Next message	2
Back to previous message	3
Save message	4
Delete message	5
Aller au menu principal	*

Main Menu	
Voicemail options	1
Exit	*

Confirm welcome message	1
Modify welcome message	2
Change password	3
Back to main menu	*

Record a new welcome message	1
Reset to default welcome message	2
Back to main menu	*

Password change	
The password enables protection access to voicemail from home, or to check voicemail remotely. Default is no password.	
Enter current password then:	#
Enter new password then:	#
Confirm new password then:	#